



Connection Schematic Diagram



Warning : Disconnect the power prior to the installation or servicing the control system.